

<b>Make/Bilmerke:</b> VW Passat 2011-	Location: Right side radio Plassering: Høyre side radio	Tape: No
		Date/Dato: 2010.11.18

English

Step 1: Unclip the frame surrounding the stereo system.

Step 2: Unscrew one of the 2 bolts that appears on passenger side of unit. We recommend to use lower bolt for position of the DashMount, but it fits perfect on upper bolt also.

Step 3: Reinstall the frame.

Norsk

Steg 1: Vipp ut panelrammen som omkranser stereosystemet.

Steg 2: Skru ut en av de 2 boltene som kommer til syne. Vi anbefaler å montere DasMounten på den nedre bolten, men det går like bra på den øvre.

Steg 3: Sett paneletrammen tilbake på plass.

TeleD AS may not be held liable for any damage to a vehicle connected to the installation.



DeutschSchritt 1: Ziehen oder hebeln Sie den Rahmen un