

<b>Make/Bilmerke:</b> Nissan Primastar 2011- Opel Vivaro 2011- Renault Trafic 2011-	Location: Left side radio Plassering: Venstre side radio	Tape: No
		Date/Dato: 2010.10.27

### English

Step 1: Remove the frame surrounding the radio unit. Pull all the way out. There is no need to disconnect wires or to use tools.

Step 2: Locate the DashMount on the screw on driver side of radio as shown in photo.

Step 3: Push the frame back into position.



### Norsk

Steg 1: Ta ut rammen rundt radioen med hjelp fingrene dine. Denne er klipset fast og trekkes rett ut. Ledninger er ikke nødvendig å koble fra.

Steg 2: Plasser DashMountens arm på skruen på førersiden av radioen, slik som vist på bildet.

Steg 3: Skyv rammen på plass igjen.



Important! Clean tape area when tape is required for maximum stability. Press hard on tape for 5-10 seconds.

NB: Rengjør i området hvor tapen skal feste for best mulig stabilitet. Press godt inn i 5-10 sek. slik at tapen fester.

TeleD AS may not be held liable for any damage to a vehicle connected to the installation.

